

-	•					
Number:	ACIS-C-006	Type:	X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	8/2/95 1/3/97 1 of 1
Subsystem Subject: Source:	ACIS Red	_		After Perigee Pass e-mail, M. Juda, 9	_	
CRL Stater	ment:					
	•			Memory (SRAM) a aded after each p	-	<u>dom</u>
	nale/Justification		ng e	each perigee pass	age.	
CRL Impac						
Damage to	ACIS CCDs.					
Recommer	nded Action:					
Incorporate Scheduling		ms and C)pera	ations Procedures	and Mission Pla	nning and
From: P. Plucinsk				Approved:		
<u>F. FIUCITISK</u>	<u>, 700</u>			M. Yerkes, APN	I, Mission Operat	tions



Number:	ACIS-R-005	Type:		Constraint	Original Date:	10/12/95
			X	Restriction	Revised Date:	12/13/96
				Limitation	Page:	1 of 1

Subsystem: ACIS

Subject: Contamination

Source: AVO JAV 96-67.DOC, "Contamination of ACIS Optical Blocking

Filter, 3 December 1996, J. Vogrin

CRL Statement:

The ACIS door is to remain closed for the first 30 days after operational orbit injection.

CRL Rationale/Justification:

After operational orbit injection, a minimum of 30 days is required to complete outgassing which includes ACIS detector housing and focal plane bakeout. Backout avoids the accumulation of unacceptable molecular contamination levels on the Optical Blocking Filter. After bakeout, ACIS can be cooled to its operating temperature for the initial Telescope calibration.

ACIS performance is degraded.

Recommended Action:	
Incorporate into the Systems ar	nd Operations Procedures, OP16 and OP17.
From: L. Ryan	Approved:
L. Ryan	M. Yerkes, APM, Mission Operations



Number:	CCDM-C-010	Type: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:	1/15/97 1/15/97 1 of 2
Subsysten Subject: Source:		nand Rates			

CRL Statement:

- A. When commanding any slice in the EIA, the maximum continuous command rate for periods of greater than one minute to any one relay shall not energize the relay coil at more than a 10% duty cycle.
- B. When commanding any slice in the EIA, the maximum continuous command rate for periods of greater than one minute shall not energize the hybrids at more than a 30% duty cycle.

CRL Rationale/Justification:

EIA design dictates that the slice command rates for periods greater than one minute, as a function of command pulse width and energizing duty cycle, be defined as follows:

		Evenly Spaced	Commands/sec
EIA Slice Command Pulse Width, msec		30% Duty Cycle, cmds/sec	10% Duty Cycle, cmds/sec
Momentary Command	<u>64</u>	<u>4.6</u>	<u>1.5</u>
Latching Command	<u>32</u>	<u>9.3</u>	<u>3.1</u>
<u>Isovalve</u>	<u>32</u>	<u>9.3</u>	<u>3.1</u>
<u>Isovalve</u>	<u>128</u>	<u>2.3</u>	<u>0.7</u>
<u>Isovalve</u>	<u>256</u>	<u>1.1</u>	<u>0.3</u>
<u>Ordance</u>	<u>32</u>	<u>9.3</u>	<u>3.1</u>



Number:	CCDM-C-010	Type:	Constraint Restriction Limitation	Original Date: Revised Date: Page:	1/15/97 1/15/97 2 of 2
Subsystem Subject: Source:		mand Rates			

Slice command rates for periods less than one minute have maximum burst command rates which are as follows:

Command Pulse Width,	Number of Evenly Spaced
<u>msec</u>	cmds/sec
<u>32</u>	<u>23</u>
<u>64</u>	<u>13</u>
<u>128</u>	<u>7</u>
<u>256</u>	<u>3</u>

CRL Impact:

- A. Thermal damage to a slice, relay, or hybrid results if the energizing duty cycle exceeds 10% or 30% respectively.
- B. Commands will be lost if the burst command rates are exceeded.

Recommended Action:	
Incorporate into the Systems and Operate	tions Procedures and A&T Procedures.
From:	Approved:
R. Parr	M. Yerkes, APM, Mission Operations



R. Parr

Constraints, Restrictions, & Limitations

Number: CCDM-L	006 T	ype: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:			
	DM A Serial C	command a	nd Telemetry Ena	able Rate			
CRL Statement:							
	The maximum serial command rate from the RCTU to the EIA is 1 command every 352 μsec. The maximum serial telemetry enable rate is 1 telemetry enable every 600 μsec.						
CRL Rationale/Just EIA design implementelemetry enable ra	entation d	<u>dictates limi</u>	ts to the serial co	mmand and seria	<u>al</u>		
CRL Impact: Loss of commands	and/or te	lemetry.					
Recommended Acti	ion:						
Incorporate into the	Systems	s and Opera		s and A&T Proce	dures.		
From:			Approved:				



Number: HRC-C-004 Type: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:	1/30/97 1/30/97 1 of 1
Subsystem: HRC Subject: HRC MCP High Volt Source: Informal CARD input	•	1/28/97	
CRL Statement:			
HRC high voltages must not be com	manded in excess of	TBD volts.	
CRL Rationale/Justification:			
The HRC sensitivity to high voltage i	s derived from the H	RC design.	
CRL Impact:			
Exceeding the allowed voltage will da	amage the HRC MC	P HV.	
Recommended Action:			
Incorporate into Systems and Opera	tions Procedures.		
From:	Approved:		1
M. Juda, ASC	M. Yerkes, APN	M, Mission Opera	tions



	Number: Hi	RC-C-005	Type:	X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	1/31/97 1/31/97 1 of 1
	Subsystem: Subject: Source:	HRC HRC Det Informal (ng e-mail, M. Juda, 1	1/28/97	
	CRL Statemer	nt:					
	HRC high voltages must be commanded off prior to switching from either the Imaging detector to the Spectroscopy detector or the Spectroscopy detector to the Imaging detector.						
	CRL Rationale			<u>witchi</u>	ng is derived from	the HRC design	<u>-</u>
	CRL Impact:						
	Detector switc	ching transie	ents will	<u>dama</u>	age the HRC prean	nplifier inputs.	
ĺ	Recommende	ed Action:					
	Incorporate in	<u>ito Systems</u>	and Op	eratio	ns Procedures.		
	From: M. Juda, ASC				Approved:		



Number:	HRC-C-006	Type:	X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	1/31/97 1/31/97 1 of 1
Subsystem Subject: Source:	HRC Hig	_		Detector Selectio e-mail, M. Juda, 1		
CRL State	ment:					
	opy, unless tha		_	to a detector, i. e been selected by		
			of hig	<u>ih voltage to detec</u>	ctors is derived fr	om the
CRL Impac		of HRC h	nigh v	oltages to a detec	ctor will damage	the
detector gr	ids.					
Recommer	nded Action:					
Incorporate	e into Systems	and Ope	ratio	ns Procedures.		
From: M. Juda, A	<u>SC</u>			Approved:		



	Number: HRC-0	C-007 Type:	X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	
	Subject: H			Electronic Calibra e-mail, M. Juda, 1		
	CRL Statement:					
	HRC high voltages electrical calibration		mande	ed off prior to turni	ng on the interna	<u>I</u>
	CRL Rationale/Jus	stification:				
	HRC sensitivity to from the HRC des		<u>hen e</u>	ntering the calibra	tion mode is deri	<u>ved</u>
	CRL Impact:					
1	HRC high voltage	switching trans	sients	will damage the H	RC preamplifier i	inputs.
•						-
	Recommended Ad	ction:				
	Incorporate into S	ystems and Op	eratio	ns Procedures.		
	From:			Approved:		



•	\sim					
Number:	PCAD-C-006	Туре:	X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	1/28/97 1/28/97 1 of 1
Subsyster	m: PCAD					
Subject: Source:		eration D	uring	Solar Storms		
CRL State	ement:					
	of the Valve Dinould be avoided		tronic	es (VDE) during s	ignificant solar sto	<u>orm</u>
CRL Ratio	onale/Justification	on:				
engine co	ntrol during orb	it injectio	n bur	ns. An upset of	S thrusters, and for the VDE during colar storms by ma	

CRL Impact:

An upset of the MUPS burn results in an incorrect momentum unloading, which if long enough, could cause the transfer to Safe Mode. An upset to the IPS burn results in either an incorrect burn duration or an unsequenced burn termination which could cause the failure of the IPS engines.

orders of magnitude depending on the severity of the storm.

Recommended Action:	
Incorporate into the Sys	stems and Operations Procedures, OFLS Mission Planning
From: R. Rose	Approved:
	M. Yerkes, APM, Mission Operations



		& Limitati	OHS
Number: PCAD-L-009 Type:	Constraint Restriction Limitation	Original Date: Revised Date: Page:	10/15/96 1/27/97 1 of 1
Subsystem: PCAD Subject: Search Commands EQ7-278 (Section 3.	.1.2.1.1)		
CRL Statement:			
Any tracked image location must be other tracked or monitored image location		st 65 arcseconds	s from all
CRL Rationale/Justification: Tracking an image within 65 arcseco interference with the ACA centroiding		ge will cause	
CRL Impact: ACA search and/or tracked image pr	rocessing will be cor	rupted.	
Recommended Action:			
Incorporate into the Systems and Op		S.	
From: D. Sargent	Approved:		
ŭ	M. Yerkes, AP	M, Mission Oper	ations



Number: PCAD-L-011 Type:	Constraint Restriction x Limitation	Original Date: Revised Date: Page:	1/27/97 1/27/97 1 of 1
Subsystem:PCADSubject:ACA Calibration TelemonySource:EQ7-278E (Section)			
CRL Statement:			
During ACA calibration, the AXAF te	elemetry rate must b	e set to 512 kpbs	<u>s.</u>
CDL Patianala/Justification			
CRL Rationale/Justification:			
This limitation is driven by the ACA	design.		
CRL Impact:			
The use of any other telemetry rate	will result in the los	s of calibration da	ata.
Recommended Action:			
Incorporate into the Systems and O	perations Procedure	<u>es.</u>	
From:	Approved:		
D. Sargent	M. Yerkes, AF	PM, Mission Oper	ations



Number:	PCAD-L-013	Type:		Constraint	Original Date:	1/28/97
				Restriction	Revised Date:	1/28/97
			Х	Limitation	Page:	1 of 2

Subsystem: PCAD

Subject: Calibration Command Sequence and Timing

Source: EQ7-278E (Section 3.1.2.1.4.4)

CRL Statement:

The ACA calibration sequence is as follows:

- A. A command must be issued to the IU to begin calibration.
- B. A command, or sequence of commands, to the ACA must be issued to begin calibration such that the first command to the ACA should be received no earlier than the command to the IU.
- C. <u>Time, T_{wait}, will be allowed for all of the commanded calibration data to be clocked out by the IU.</u>

 $T_{\text{wait}} = (T_{\text{int}} + 1.0) * M + 0.02 * N + 5.0$

where T_{wait} = waiting time,

 T_{int} = integration time,

M = number of calibration commands issued, and N = total number of CCD rows to be read out by the M commands,

- D. Following a delay of least T_{wait}, a command must be issued to the ACA to stop calibration, and
- E. A command must be issued to the IU to stop clocking calibration data such that there is at least a 2 second delay between the receipt, by the ACA, of the command to stop calibration and the receipt, by the IU, of the command to stop clocking.



D. Sargent

Constraints, Restrictions, & Limitations

Number: F	PCAD-L-013	Type:	X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	1/28/97 1/28/97 2 of 2
Subsystem: Subject:	Calibration			Sequence and Tin	ning	
Source:	EQ7-278	E (Section	on 3.1	1.2.1.4.4)		
CRL Ration	ale/Justification	on:				
	tion command e ACA design	-	<u>ce an</u>	d command timing	g delay limitation	<u>is</u>
CRL Impact	t:					
	atisfy the calib			ind sequence and	command timing	<u>delays</u>
Recommend	ded Action:	_	_			
Incorporate	into the Syste	ems and	Oper	ations Procedures	s, A&T Procedure	es.
From:				Approved:		



Number:	PROP-C-001	Type:	Χ	Constraint	Original Date:	2/23/95
				Restriction	Revised Date:	<u>1/8/97</u>
				Limitation	Page:	1 of 2

Subsystem: Propulsion
Subject: Isolation Valve

Source: AXAF IPS PDA, 24 August 1994, PS Review, Dec. 8, 1995

CRL Statement:

- A. After the isolation valve is actuated, the enable/disable relay should, within 20 seconds, be opened to disable power being applied to the valve. (Applicable for both ground or flight operations.)
- B. During storage or other non-flight inoperative periods, PS shall be configured with all latching isolation valves open.
- C. Following launch, the isolation valve position must be re-established by sending appropriate commands to position the values as required, i. e., open, irrespective of the launch configuration.

CRL Rationale/Justification:

- A. Application of continuous power to the isolation valve coils <u>heats the isolation</u> valve coils.
- B. <u>Keeping all latching isolation valves open is the preferred configuration for storage or non-flight periods.</u> The valves should not be closed unless necessary.
- C. Activation of the PS requires that the isolation valves be open.



Number:	PROP-C-001	Type:	Х	Constraint Restriction Limitation	Original Date: Revised Date: Page:	2/23/95 1/8/97 2 of 2
Subsyster Subject: Source:	Isolation \	√alve	24 Aug	ust 1994, PS Re	view, Dec. 8, 199	95
CRL Impa	act:					
OIL IIIpe	iot.					
A. Propel	llant overheating	and/or	valve	coil damage.		
C. Propul	sion system can	inot be a	<u>activat</u>	ed.		
Recomme	ended Action:					
Incorpora	te into the Syste	ms and	Opera	ations Procedures	S.	
From:				Approved:		
N. Mayer				M. Yerkes, API	M, Mission Opera	ntions



Number:	PROP-C-003	Type:	Х	Constraint	Original Date:	2/23/95
				Restriction	Revised Date:	10/31/96
				Limitation	Page:	1 of 2

Subsystem: Propulsion

Subject: Liquid Apogee Engine - Handling/Processing Constraints

Source: LAE Handling Literature

CRL Statement:

- A. Protective covers (wrappings) on nozzle exit cone shall only be removed in a clean environment by personnel wearing clean, lint-free gloves.
- B. The valves shall only be electrically actuated per approved test procedures and using a <u>PS-</u>approved electrical power source designed for this purpose. At no time shall either valve be energized at full power for more than one minute without internal gas or liquid flow (at <u>PS-approved</u> flow rates).
- C. The nozzle exit cone is very thin and can be readily damaged by moderate contact with other objects. The exterior protective cover for the chamber and exit cone shall be <u>in place</u> during all operations <u>and storage</u>, except when it must be removed for LAE installation or test purposes.
- D. The disilicide coating on the chamber and nozzle is sensitive to damage by contamination. No labels, bonding, paint, tape, or markings shall be applied to this surface. Only fluids approved by TRW shall contact these surfaces and then only when absolutely necessary. All handling of the LAE shall be done with clean, lint-free gloves.
- E. Only clean, approved fluids (GHe, GN₂, or leak test gas per MT9-2) shall be flowed through the engine and only per procedures approved by the PS subproject.
- F. The LAE must never be backflowed with any fluid (liquid or gas).
- G. Relative to the LAE head<u>-end</u>, the engine nozzle must always be maintained at or below horizontal position<u>during Spacecraft acoustic and vibration</u> testing, storage, transportation, and launch.



Number:	PROP-C-003	Type: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:	2/23/95 10/31/96 2 of 2
Subsysten Subject: Source:	Liquid Ap			cessing Constraint	ts
CRL State	ment:				
temper		r or Copper	•	6-1) may occur at 6 be allowed next to	
	alves are dry cyc ed in valve cycle		Ory cycles must	be minimized and	
	onale/Justificatio		e actions protec	ot the LAEs from da	amage.
CRL Impa					I
LAE dama	<u>ige.</u>				
Recomme	nded Action:				
Incorporat	e into Systems	and Operati	ons Procedures	and A&T Procedu	res.
From:	•	•	Approved:		
N. Mayer			M Verkes /	APM Mission One	rations



Number:	PROP-C-	006 Typ	e: x	Constraint Restriction Limitation	•	8/18/95 10/31/96 1 of 2
Subsyster	m: Prop	ulsion				
Subject:	Fibe	r-Wound T	anks			
Source:	AXA	F PDA, EC	28-0326	6, EQ8-0349		

CRL Statement:

- A. Propellant and pressurant tanks shall never be stored for a period of more than 24 hours without a GN₂ or GHe blanket pressure of 5-50 psig. This is a concern during backfilling of an electron beam welding chamber, heat treatment or during spacecraft level vacuum testing and storage.
- B. Protective covers are required on overwrapped tanks when exposed and susceptible to damage.
- C. All pressure cycles above 25 psig must be recorded in the pressure cycle log to verify that the total cycle limitation is not exceeded.

CRL Rationale/Justification:

- A. The propellant and pressurant tank assemblies are not designed to withstand external pressure greater than their internal pressure.
- B. <u>Protective covers on overwrapped tanks satisfy safety requirements per the KSC Safety Letter Ground Hazard Report G14.</u>
- C. The propellant and pressurant tank assumblies are pressure cycle limited.



Number:	PROP-C-006	Type: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:	8/18/95 10/31/96 2 of 2
Subsysten Subject: Source:	Fiber-Wo	und Tanks	6, EQ8-0349		
05					
CRL Impa	ct:				
Tank dama	age.				
Recomme	nded Action:				
Incorporat	e into A&T Prod	cedures.			
From: N. Mayer			Approved:		
. t. Mayor			M Verkes	APM Mission One	rations



Number:	PROP-C-007	Type:	X	Constraint Restriction Limitation	<u> </u>	Original Date: Revised Date: Page:	
Subsystem Subject: Source:	n: Propulsion RCS 20-lk Kaiser Ma	of REM					

CRL Statement:

- A. Maintain catalyst bed horizontal or below valve at all times <u>during Spacecraft</u> <u>acoustic and vibration testing, transportation, and launch.</u>
- B. Protective covers and caps shall be installed at all times on thrusters when there is no outward flow from the respective units.
- C. Thruster valves shall only be electrically actuated per approved test procedures and using an approved electrical power source designed for this purpose. At no time shall the valve be energized at full power for more than TBD seconds without internal gas or liquid flow (at TRW approved flow rates).
- D. Dry cycles must be limited and all cycles recorded.

CRL Rationale/Justification:

- A. Prevents back-migration of catalyst fines into the injector.
- B. Potential thruster damage is mitigated using protective covers and caps.
- C. TRW approved test procedures mitigate potential overheating the thruster valves.
- D. Thruster valves are dry cycle limited.



Number: PROP-C-007 Type: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:	8/14/95 10/31/96 2 of 2
Subsystem: Propulsion Subject: RCS 20-lbf REM Source: Kaiser Marquardt			
CRL Impact:			
A. Fuel leakage and/or degraded thrus	ster performance	<u>.</u>	
B. Thruster damage.			
C. Thruster valve damage.			
D. Exceeding dry cycle limits potential	ly damages the tl	hruster valves.	
Recommended Action:			
Incorporate into A&T Procedures.			
From:	Approved:		
N. Mayer	M. Yerkes, AF	PM, Mission Oper	ations



Number:	PROP-C-008	Type:	X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	8/14/95 10/31/96 1 of 2
Subsyster Subject:	•)ual ⁻	Thrust Module		

CRL Statement:

Source:

TRW

- A. Maintain catalyst bed horizontal or below valve at all times <u>during Spacecraft</u> acoustic and vibration testing, transportation, and launch.
- B. Protective covers and caps shall be installed at all times on thrusters when there is no outward flow from the respective units.
- C. Thruster valves shall only be electrically actuated per approved test procedures and using an approved electrical power source designed for this purpose. At no time shall the valve be energized at full power for more than TBD seconds without internal gas or liquid flow (at TRW approved flow rates).
- D. Dry cycles must be limited and all cycles recorded.

CRL Rationale/Justification:

- A. Prevents back-migration of catalyst fines into the injector.
- B. Potential thruster damage is mitigated using protective covers and caps.
- C. TRW approved test procedures mitigate potential overheating the thruster valves.
- D. Thruster valves are dry cycle limited.



Number: PROP-C-008 Type: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:			
Subsystem: Propulsion Subject: MUPS MRE-0.1 Dual 7 Source: TRW	hrust Module				
CRL Impact:					
A. Fuel leakage and/or degraded thrus	ter performance.		[
B. Thruster damage.					
C. Thruster valve damage.					
D. Exceeding dry cycle limits potentiall	D. Exceeding dry cycle limits potentially damages the thruster valves.				
Decembered Actions			_		
Recommended Action:					
Incorporate into A&T Procedures. From:	Approved:				
N. Mayer	Approved.				
	M. Yerkes, API	M, Mission Oper	ations		



Number: PROP-C-010 Tyl	pe: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:	10/31/96 10/31/96 1 of 1			
Subsystem: Propulsion Subject: Pressure Reg Source:	julator						
CRL Statement:							
The pressure regulators must never be back flowed. Any testing involving the pressure regulators requires approval of the Propulsion Subsystem Engineer.							
CRL Rationale/Justification:	CRL Rationale/Justification:						
The pressure regulators are sensitive to back flow.							
CRL Impact:							
Pressure regulator damage.							
Recommended Action:							
Incorporate into the Systems a	and Opera		<u>98.</u>				
From: N. Mayer		Approved:					
		M Varkas AE	Mission One	rations			



Number: PROP-C-011 Type: x	Constraint Restriction Limitation	Original Date: Revised Date: Page:	10/31/96 10/31/96 1 of 1			
Subsystem: Propulsion Subject: MUPS Tank Source:						
CRL Statement:						
A. All pressure cycles must be recorded in the pressure cycle log.						
B. The MUPS tank diaphragm must never bottom out on the gas side.						
CRL Rationale/Justification:						
A. The MUPS tank is pressure cycled li	mited.					
B. A positive pressure must always be	maintained on tl	ne gas side.				
CRL Impact:						
A. Exceeding the total cycle limitation m	nay result in tan	k damage.				
B. Tank and/or diaphragm damage.						
Recommended Action:						
Incorporate into the Systems and Opera						
From: N. Mayer	Approved:					
	M. Yerkes, AF	PM, Mission Oper	ations			



Number:	PROP-R-002	Type:	Constraint x Restriction Limitation	Original Date: Revised Date: Page:	8/11/95 <u>1/9/97</u> 1 of 1
Subsyster Subject:	•		ases Entering PS		

CRL Statement:

Source:

A. Liquid entering the PS shall be filtered to 5.0 microns absolute. Gases shall be filtered to 0.5 micron absolute.

AXAF PS PDA Package, 24 August 1994

B. All gases entering the PS shall have a dryness level of -45.0°F dew point or dryer.

CRL Rationale/Justification:

- A. This filtration helps protect PS components from contamination.
- B. This dryness level helps prevent moisture from entering the PS.

CRL Impact:

- A. PS contamination and performance degradation.
- B. PS component corrosion and/or leakage.

Recommended Action:	
Incorporate into A&T Procedures.	
From:	Approved:
N. Mayer	M. Yerkes, APM, Mission Operations



Number: PROP-R-007 Type:	Constraint Restriction Limitation	Original Date: Revised Date: Page:	10/31/96 10/31/96 1 of 1		
Subsystem: Propulsion Subject: Source: Propulsion Subsystem Cleanlin	iess				
CRL Statement:					
Internal flow passages shall only be exposed to a clean room environment meeting class 10,000 of Federal Standard 209. This can be excepted if filters per the filtration of liquid/gases entering PS (PROP-R-002) are installed in a clean room prior to exposing internal flow passages.					
CRL Rationale/Justification:					
Protection of the internal cleanliness of the PS.					
CRL Impact:					
LAE component contamination and performance degradation.					
Recommended Action:					
Incorporate into the Systems and O	perations Procedure	<u>)S.</u>			
From: N. Mayer	Approved:				
	M. Yerkes, AF	PM, Mission Oper	ations		



	Number: PROP-R-008 Type:	: Constraint x Restriction Limitation	Revised Date:	
	Subsystem: Propulsion Subject: Fill and Drain Va	alve Cycling		
	CRL Statement:			
	Slave valves should be installed	d and utilized for re	peated testing.	
	CRL Rationale/Justification:			
	The minimized cycling of the fill drain valve cycle requirement.	and drain valve wi	Il avoid exceeding the	e fill and
	CRL Impact:			
	Fill and drain valve cycle require	ements violation.		
ſ	Recommended Action:			
	Incorporate into the Systems an	nd Operations Proc	raduras	
֓֞֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֓֓֓֓֓֜֜֜֜֜֜֜֜֜֜	From:	Approved		
Ì	N. Maver	امار ،	u.	



Number: PROP-R-009 Type:

.

Constraint Restriction Limitation Original Date: 2/23/95
Revised Date: 11/19/96

Page: 1 of 1

Subsystem: Propulsion

Subject: Liquid Apogee Engine - Firing Constraints

Source: AXAF IPS PDA, 24 August 1994, PS Review, Dec. 8, 1995

CRL Statement:

The Spacecraft nominal attitude before and after the repositioning for LAE firings is **-Z** axis pointing to the sun, i. e., -90° pitch, 0° roll.

CRL Rationale/Justification:

At Spacecraft pitch attitudes less than -75°, direct solar heating of the head-end of the LAE injector will occur. At the worst LAE solar heating case pitch angle of -45°, the injector temperature may exceed 150°F within 2 hours (without injector heaters powered). Thus, to ensure compliance with the LAE firing constraint PROP-C-002(A) with respect to the maximum allowable temperature, the times at pitch angles less than -75° must be minimized (<< 2 hours).

CRL Impact:

Autonomous termination of LAE burn.

Recommended Action:	
Incorporate into the Syste	ms and Operations Procedures.
From:	Approved:
L. Harper	M. Yerkes, APM, Mission Operations



Number:	PROP-L-001		X	Constraint Restriction Limitation	Original Date: Revised Date: Page:	8/11/95 1/10/97 1 of 1
Subsysten Subject: Source:	MUPS/R	CS Cross		r Pyrovalve Mayer, 8/95		
CRL State	ment:					
Nominal MUPS operations may not be immediately available following the activation of the cross over pyrovalve.						
	nale/Justificati			valva Clila masv sv	otor the MUDO fo	
lines.	ation of the <u>cr</u>	<u>oss</u> <u>over þ</u> ý	yro v	/alve, GHe may er	ner the MOPS it	Jei
CRL Impa	ct:					
Pulses will be missed until gas bubbles are purged from the lines.						
Recomme	nded Action:					_
		and Oper	atior	ns Procedures.		
From:		3		Approved:		
N. Mayer				M. Yerkes, APN	I, Mission Opera	ations



Number:	THER-C-003	Type:	Х	Constraint	Original Date:	8/28/96
				Restriction	Revised Date:	<u>10/15/96</u>
				Limitation	Page:	1 of 1

Subsystem: Thermal

Subject: RF Downlink Prior to Eclipse Entry

Source: AXAF.96.323.097, RF Downlink Prior to Long-Eclipse Entry

Operational Constraint Details, 9 July 1996.

CRL Statement:

The RF downlink must be operating in the high power mode three hours prior to entry into, and during, an eclipse of one hour duration (or greater).

CRL Rationale/Justification:

To minimize eclipse heater power, it is required that the RF downlink (Power Amplifier and Transponder) be activated in high power mode with a modulated signal, i. e., the downlink transmission of telemetry, at least three hours prior to entry into an eclipse of greater than one-hour duration. Activation (fully powered up) must be maintained up to eclipse entry.

CRL Impact:

If RF component heaters operate during eclipse, the batteries may <u>exceed the</u> allowed depth of discharge prior to eclipse exit.

Recommended Action:	
Incorporate into Systems and	d Operations Procedures.
From: P. Knollenberg	Approved:
ğ	M. Yerkes, APM, Mission Operations

52100.500.007 TRW-OP05 23 Oct 96